468 931 003 798-1

Für den Installateur Installationsanleitung *FITnp 3U* (D)

1 Verwendung

Der Universal-Temperaturregler *FITnp 3U* vereint Regler für 3 unterschiedliche Anwendungen in einem Gerät.

Folgende Heizungsarten können ausgewählt werden:

- Raumtemperaturregler
- Raumtemperaturregler mit Begrenzer
- Fußbodentemperaturregler

2 Heizungsart auswählen

Installateur Einstellungen auswählen, dazu:

- Taste **MENÜ** drücken, dann mit Taste **+** durch die Menüs bewegen
- Bei „Installateuer Einstellungen“ **OK** drücken

CODE = 7 eingeben

- Mit **OK** bestätigen

H1 = Heizungsart wählen

- Mit **OK** bestätigen
- **Heizungsart** einstellen (RAUM, BEGRENZER, BODEN)
  BODEN ist voreingestellt
- Mit **OK** bestätigen

Hinweis:

Bei Wechsel der Heizungsart werden alle Benutzer- und Installateur-Einstellungen auf deren Voreinstellung gesetzt.

3 Anleitung

Je nach gewählter Heizungsart die passende Anleitung verwenden für:

RAUM = FITnp 3R für Raumtemperaturregler
BODEN = FITnp 3F Fußbodentemperaturregler
BEGRENZER = FITnp 3L für Raumtemperaturregler mit Begrenzer

Beim Kunden sollte nur die jeweils passende Anleitung zurückgelassen werden.

468 931 003 798-1

For the Installer Installation manual *FITnp 3U* (GB)

1 Use

The Universal Temperature Controller *FITnp 3U* combines controllers for 3 different applications.

The following applications can be selected

- Room Temperature Controller
- Room Temperature Controller with Limiter
- Floor Heating Controller

2 Select application

Select Installer settings

- Press key **MENU** then move forward with key **+**
- At “Installer settings” press **OK**

CODE = 7

- Press **OK**

Select H1 = Application

- Press **OK**
- Select **Application** (ROOM, LIMITER, FLOOR)
  FLOOR is factory pre-set
- Press **OK**

Note:

In case of changing the application, the user- and Installer-settings will be set to it's default values.

3 Manual

Depending on selected application the suitable manual has to be used:

ROOM = FITnp 3R for Room Temperature Controller
FLOOR = FITnp 3F for Floor Temperature Controller
LIMITER = FITnp 3L for Room Temperature Controller with Limiter

With the customer only the suitable manual should be left.